



Code	Colour
BK	Black
BN	Brown
RD	Red
OG	Orange
YE	Yellow
GN	Green
BU	Blue
VT	Violet
GY	Grey
WH	White
PK	Pink

  

Des.	Pos.	Description
C12	C 8	Connector, 21-pole
C18	C 3	Connector, 15-pole
C19	E 3	Connector, 21-pole
C25	C 3	Connector, 15-pole
C218	C 4	Connector, 21-pole
C8159	D 7	Splice, AUS, Instr
E130	E 2	Control unit, infotainment system
G4-2	D 6	Splice, ground
G8-3	C 8	Splice, ground
G66-1	C 4	Splice, ground
N3	E 3	Loud speaker, treble driver
N4	F 3	Loud speaker, CB passenger
N5	F 3	Loud speaker, CB radio
N16	B 4	Subwoofer
N20	C 2	Loud speaker, door driver
N21	C 3	Loud speaker, door passenger
P2.BX48	E 6	Fuse socket, central electric unit
P2.BX50	E 5	Fuse socket, central electric unit
U28	C 7	USB, charge
U29	C 6	USB, charge
U30	C 6	USB, charge
U31	B 8	USB, charge rear

Infotainment RHD & USB charge

Circuit Diagram:

**AUS**

Drawing No.- 2086546-2-5  
 Sheet-Rev:

N.B. The copyright and ownership of this drawing including associated computer data are and will remain ours. They must not be copied, used or brought to the attention of any third party without prior permission (C) Scania, Sweden