


Des.	Pos.	Description
C9	C 7	Connector, 15-pole
C14	B 2	Connector, 15-pole
C28	E 2	Socket, 2-pole, 24V outlet
C41	B 4	Junction block
C56	C 4	Supply feed through
C78	B 2	Connector 21-pole IP-Floor
C168	E 2	Socket, 2-pole, 12/24V Outlet
C273	A 3	Connector, 21-pole
C407	A 2	Socket, 2-pole, 24V outlet
E34	F 2	Voltage converter
G1	C 2	Joint connector, ground
G2	C 1	Joint connector, ground
G3	C 1	Joint connector, ground
G4	C 8	Joint connector, ground
G5	C 6	Joint connector, ground
G8	A 2	Joint connector, ground
G9	B 3	Joint connector, ground
G10	A 4	Ground, roof
G12	D 6	Ground, 40-circuit unit
G13	C 5	Ground, torpedo wall
G14	C 1	Ground, torpedo wall
G15	C 6	Ground, torpedo wall
G16	A 3	Ground, roof
G20	A 5	Ground, cab front
G30	A 5	Ground, frame
G32	A 5	Ground, frame
G48	B 2	Ground, floor
M1	A 4	Starter motor
P1 A	A 4	Battery
P1 B	A 5	Battery
P2	E 4	Central electric unit



Code	Colour
BK	Black
BN	Brown
RD	Red
OC	Orange
YE	Yellow
GN	Green
BLU	Blue
VT	Violet
GY	Grey
WH	White
PK	Pink

**SCANIA**

Circuit Diagram:  
**POW**

Drawing No.- 1395800-1-23  
Sheet-Rev.

N.B. The copyright and ownership of this drawing including associated computer data are and will remain ours. They must not be copied, used or brought to the attention of any third party without prior permission (C) Scania, Sweden

For connection with battery master switch service see sheet 2.  
For connection with battery master switch safety see sheet 3.  
For connection with battery bypass see sheet 4.

Placed in floor only on Crew cab