


Des.	Pos.	Description
C9	C7	Connector, 15-pole
C14	B2	Connector, 15-pole
C28	E2	Socket, 2-pole, 24V outlet
C41	B4	Joint connector
C55	C4	Supply feed through
C78	B2	Connector 21-pole IP-Floor
C180	E2	Socket, 2-pole, 12/24V Outlet
C273	A3	Connector, 21-pole
C407	A2	Socket, 2-pole, 24V outlet
E34	F2	Voltage converter
G1	C2	Joint connector, ground
G2	C1	Joint connector, ground
G3	C1	Joint connector, ground
G4	C8	Joint connector, ground
G5	C6	Joint connector, ground
G8	A2	Joint connector, ground
G9	B3	Joint connector, ground
G9	B3	Joint connector, ground
G10	A4	Ground, roof
G10	A3	Ground, roof
G12	D6	Ground, el-central unit
G13	C5	Ground, torpedo wall
G14	C1	Ground, torpedo wall
G15	C6	Ground, torpedo wall
G16	A3	Ground, roof
G20	A5	Ground, cab front
G30	A5	Ground, frame
G32	A3	Ground, frame
G48	A2	Ground, floor
M1	A4	Starter motor
PTA	A4	Battery
PTB	A5	Battery
P2	E4	Central electric unit



Code	Colour
BK	Black
BN	Brown
RD	Red
OG	Orange
YE	Yellow
GN	Green
BLU	Blue
VV	Violet
GY	Grey
WH	White
PK	Pink

**SCANIA**

Circuit Diagram:

**POW**

Drawing No.- 1395800-1-24  
Sheet-Rev.

N.B. The copyright and ownership of this drawing including associated computer data are and will remain ours. They must not be copied, used or brought to the attention of any third party without prior permission (C) Scania, Sweden

For connection with battery master switch service see sheet 2.  
For connection with battery master switch safety see sheet 3.  
For connection with battery bypass see sheet 4.

Placed in floor only on Crew cab