



Code	Colour
BK	Black
BN	Brown
RD	Red
OG	Orange
YE	Yellow
GN	Green
BU	Blue
VT	Violet
GY	Grey
WH	White
PK	Pink

Des.	Pos.	Description
C8	C 9	Connector, 2-pole
C41	D 11	Junction block
C100	E 8	Connector, 66-pole
C100	E 8	Connector, 66-pole
C100	E 7	Connector, 66-pole
C103	E 7	Connector, 66-pole
C275	H 6	Joint connector, instr light
C334	D 7	Connector, 6-pole
C405	D 7	Connector, 2-pole
E59	B 4	Control unit, battery master switch
F8	D 9	Fuse
F8/C8	D 8	Fuse
G2	F 6	Joint connector, ground
G4	G 7	Joint connector, ground
G32	A 10	Ground, frame
P1.A	A 11	Battery
P1.B	A 11	Battery
P2	H 7	Central electric unit
R70	C 10	Relay, ADR, instr
R77	F 7	Relay, ADR, instr
S40	C 5	Switch, battery master switch
S73	G 6	Switch, ADR, POW

- 1) with ADR class EX/II or EX/III or AT or OX
- 2) with ADR class FL.
- 3) without ADR.

With battery master switch safety

STD
4247

S-order equipment connected:
Cir dgm POW Nordic Tractor
Cir dgm BOL.
Cable h POW ADR batt.

Circuit Diagram:

POW

Drawing No.-
Sheet-Rev: **1395800-3-9**

N.B. The copyright and ownership of this drawing including associated computer data are and will remain ours. They must not be copied, used or brought to the attention of any third party without prior permission (C) Scania, Sweden