



Des.	Pos.	Description
C9	C 5	Connector, 15-pole
C14	C 5	Connector, 15-pole
C19	C 6	Connector, 21-pole, Instr-Roof
C218	C 7	Connector, 21-pole
C301	E 5	Connector, 1-pole, GPS
C337	C 4	Splice, Instr. AUS
C412	E 6	Connector, 2-pole
C490	E 5	Connector, COAX
E34	D 5	Voltage converter
E92	D 3	Control unit, FM radio w. Navi
N3	A 6	Loud speaker, treble driver
N4	A 6	Loud speaker, treble passenger
N13	A 5	Loud speaker, door driver
N14	A 5	Loud speaker, door passenger
O1	D 8	Combination instrument
O1	F 6	Combination instrument
S89	A 8	Switch, radio LH
S93	A 8	Switch, radio RH
U1	F 5	Aerial, radio
U6	C 8	Spring coil
U11	F 5	Aerial, RTI/SVI, GSM/GPS/Radio
U18	B 4	Aux radio input



Code	Colour
BK	Black
BN	Brown
RD	Red
OG	Orange
YE	Yellow
GN	Green
BU	Blue
VT	Violet
GY	Grey
WH	White
PK	Pink



Notes:
1. LHD
2. RHD

2-DIN Radio

SCANIA

Circuit Diagram:

AUS

Drawing No.- 1878697-2-8
Sheet-Rev:

N.B. The copyright and ownership of this drawing including associated computer data are and will remain ours. They must not be copied, used or brought to the attention of any third party without prior permission (C) Scania, Sweden