



Code	Colour
BK	Black
BN	Brown
RD	Red
OG	Orange
YE	Yellow
GN	Green
BU	Blue
VT	Violet
GY	Grey
WH	White
PK	Pink

Des.	Pos.	Description
C18	C 3	Connector, 15-pole
C19	D 2	Connector, 21-pole
C25	C 2	Connector, 15-pole
C261	F 7	Connector, 21-pole
C490	D 6	Connector, coax
C8015	B 7	Connector, 21-pole
C8107	D 5	Connector, 1-pole
C8108	D 5	Connector, 1-pole
C8126	B 4	Socket, USB data
E130	D 2	Control unit, infotainment system
G3-3	D 7	Splice, ground
G8-3	B 7	Splice, ground
N3	D 4	Loud speaker, treble driver
N4	E 2	Loud speaker, treble passanger
N5	E 3	Loud speaker, CB radio
N16	A 7	Subwoofer
N20	B 3	Loud speaker, door driver
N21	B 2	Loud speaker, door passanger
O1	B 6	Instrument cluster
P2.BX50	F 8	Fuse socket, central electric unit
P2.CX151	F 6	Fuse socket, central electric unit
P2.CX155	F 6	Fuse socket, central electric unit
U18	B 5	Radio input, aux
U19	F 4	Splitter, aerial
U24	F 3	Microphone
U26	F 5	Aerial, FM/AM, DAB, MOB, GPS

Notes:

1. Std
2. Entry
3. Screen is connected to housings.

For instruction, see corresponding Bundle Drawings

AUS Standard & Entry

SCANIA

Circuit Diagram:

AUS

Drawing No.-
Sheet-Rev: 2086546-1-8

N.B. The copyright and ownership of this drawing including associated computer data are and will remain ours. They must not be copied, used or brought to the attention of any third party without prior permission (C) Scania, Sweden